

PAY RECEPTACLE LOCATION

The Pay Receptacle is located on the right side of the coin box.

TAP & PAY at Fill Station

- 1. Set up your hose.
- 2. Scan the QR code **or** tap your card.
- 3. Water will begin filling almost immediately.
- 4. Press **STOP** on the screen when you are finished.
- 5. A **digital receipt** can be obtained by **scanning the QR code on the screen** after you press **STOP**.
- **Note:** 1 cube = approximately **1 minute** of fill time.

FOB TAP at Fill Station

- 1. Set up your hose.
- 2. Place your key fob on the reader until you hear **one beep**.
- 3. Flow will start when you hear **two beeps**, indicating the transaction has been approved.
- 4. To stop the flow, place your key fob on the reader again until you hear **one beep**.
- 5. A receipt will automatically be emailed to the email address associated with your account once the transaction is complete.
- **Note:** 1 cube = approximately **1 minute** of fill time.

▲ IMPORTANT:

Water begins filling **almost instantly** once your transaction starts. Please ensure your water fill setup is **ready for use before starting your transaction.**